



IV 051003

Minimum Volume Extension Set

165cm Standard Injection Site



INSTRUCTION FOR USE

DESCRIPTION:

m|devices IV Minimum Volume Extension Set with standard injection site is 165cm in length. This set has a click clamp and a female luer lock to male luer lock with rotating collar. The set should always be primed prior to connecting to a peripheral catheter or access device on an IV administration set.

FOR USE BY A QUALIFIED CLINICIAN. THE BELOW IS ONLY A SUGGESTION AND FACILITY PROTOCOL MUST BE FOLLOWED FOR ALL CLINICAL PROCEDURES WHERE THIS PRODUCT IS USED.



CAUTION

DO NOT use if the package or product has been damaged or contaminated.
DO NOT store at extreme temperatures and humidity, avoid direct sunlight.

STEPS:

Ensure aseptic technique is followed at all times

1. Remove protective cap from female luer connector.
2. Connect a pre-filled syringe or IV administration set with sterile fluid to female luer connector.
3. To prime line using a syringe, invert the standard injection site and depress plunger to flush fluid through the set and until the fluid drips out of the distal end of the extension set. Check to ensure that all air from extension set tubing has been expelled. If air bubbles are still visible, continue flushing until completely removed.
4. To prime line by connecting to an already existing primed IV administration set, open roller clamp on IV administration set, invert standard injection site and allow fluid to flow through extension set tubing until it drips out of the distal end of the set. Check to ensure that all air from extension set tubing has been expelled. If air bubbles are still visible, continue flushing until completely removed. Close roller clamp.
5. Remove protective cap from male luer connector.
6. Connect and secure by inserting male luer connector into access device or peripheral catheter and engage rotating collar.

USING THE STANDARD INJECTION SITE:

- Swab access site with antiseptic before use.
- Connect a syringe with a needleless blunt tip cannula and push directly into injection site.
- Hold the injection site whilst removing the blunt tip cannula with syringe.
- Repeat above steps each time the injection site is accessed.

PRECAUTION:

- The security of all connections should be checked once the circuit is established and monitored during use to prevent disconnection.

m|devices

27 Llewellyn Avenue
Villawood NSW 2163 Australia
T +61 (0)2 8718 2900
F +61 (0)2 8718 2801
mdevices.com.au

m|devices®