# m|devices<sup>®</sup>

## IV051010

Minimum Volume Extension Set 150cm Anti-Siphon Valve



### **DESCRIPTION**

m|devices IV Minimum Volume Extension Set with Anti-Siphon Valve and click clamp is 150cm in length. The configuration reveals a male luer lock with rotating collar on one end and the Anti Siphon Valve on the opposing end.

Anti-Siphon Valves when used for pump/syringe driver applications, reduce the likelihood of inadvertent infusions. The normally closed diaphragm allows flow in one direction whilst checking flow in the opposite direction, preventing retrograde flow.

The set should always be primed prior to connecting to a peripheral catheter or access device on an IV administration set.

FOR USE BY A QUALIFIED CLINICIAN. THE BELOW IS ONLY A SUGGESTION AND FACILITY PROTOCOL MUST BE FOLLOWED FOR ALL CLINICAL PROCEDURES WHERE THIS PRODUCT IS USED.

## 

- · Single use only.
- . DO NOT re-sterilise.
- DO NOT store at extreme temperatures and humidity, avoid direct sunlight. Handle with care.
- . STERILE (EO), DO NOT use if the package or product has been damaged or contaminated.
- EU Notice: any serious incident that has occurred in relation to the device should be reported to the manufacturer and the competent authority of the Member State in which the user and /or patient is established.

#### **STEPS**

Ensure aseptic technique is followed at all times.

- 1. Remove protective cap from the Anti-Siphon Valve.
- 2. Connect a pre-filled syringe or IV administration set with sterile fluid to the Anti-Siphon Valve.
- 3. To prime line using a syringe, depress plunger to flush fluid through the set and until the fluid drips out of the distal end of the extension set. Check to ensure that all air from extension set tubing has been expelled. If air bubbles are still visible, continue flushing until completely removed.
- 4. To prime line by connecting to an already existing primed IV administration set, open roller clamp on IV administration set and allow fluid to flow through extension set tubing until it drips out of the distal end of the set. Check to ensure that all air from extension set tubing has been expelled. If air bubbles are still visible, continue flushing until completely removed. Close roller clamp.
- 5. Remove protective cap from male luer connector.
- 6. Connect and secure by inserting male luer connector into access device or peripheral catheter and engage rotating

## **PRECAUTION**

• The security of all connections should be checked once established and monitored during use to prevent disconnection.

## mldevices

27 Llewellvn Avenue Villawood NSW 2163 Australia T +61(0)2 8718 2800 F +61(0)2 8718 2801



Extension Sets



BQ Plus Medical Co., Ltd. No. 18, Che Ye Road Che Dun Town, Songjiang 201611 Shanghai, China

EC REP Prolinx GmbH Brehmstr. 56

40239 Duesseldorf Germany









